




FULL FOGGER USER MANUAL




GENERAL INFORMATION

The Venue™ Full Fogger is ideal for making your lights and lasers look their optimal best. Please follow the instructions below and your new fogger will give you many years of reliable service.


HOW TO OPERATE

Place the machine horizontally and fill the fluid tank with fog juice.




Connect the machine to the proper power supply (120Vac, 60Hz).

Wait until the indicator light on the machine (or on remote) illuminates before pressing the fog button.



After the machine warms up, it can be operated continuously.

You should turn off the machine before refilling.



MAINTENANCE

- Always use a high quality fog liquid such as Black Label Fog Fluid, made specifically for Full Foggers.
- Do not operate the machine when fluid is low. Be careful not to exceed the maximum fluid level.
- To maintain optimum performance and minimize wear, unit should be cleaned frequently -- usage and environment are contributing factors in determining how often. As a general rule, unit should be cleaned after every 40 hours of use. Clean with a solution of 80% water and 20% vinegar. Empty the tank of any remaining fog liquid and pour in the water and vinegar solution. Spray until the tank is empty. Clean the nozzle separately with a 100% vinegar solution. Dust build up, and/or using heavy fog fluid may reduce fog output performance and can cause overheating. This can lead to a reduction in the fogger's life and will increase mechanical wear.
- Be sure to power off unit before conducting maintenance.
- If you experience low output, mechanical noise, or no output at all, please unplug immediately. Check the fluid level, the external fuse, remote connection, and the power from the wall. If all of these are OK, plug the unit in again. If fogger does not function after 30 seconds, disconnect power or permanent damage to the unit may result. Return the machine to your dealer. Always drain the tank before mailing or transporting the unit.
- Unplug the unit when not in use.
- In the unlikely event your unit may require service, please contact your dealer or visit www.venueightingeffects.com

SPECIFICATIONS

Power input:	AC 120Vac 60HZ	Output:	1,500 cu.ft./min
Heater:	450 Watts	Tank Capacity:	500ml
Fuse:	5A 125V	Remote:	Wire Remote
Warm-up Time:	5 Minutes	Size:	L 8.66" x W 8.66" x H 5.9"
		Weight:	4.85 lbs./2.19 kg.

IMPORTANT SAFETY INSTRUCTIONS

For your safety, please read the following safety information carefully before installation and operation.

1. For indoor use only.
2. Use the AC power that complies with local building and electrical codes.
3. Ensure that the voltage and frequency match the power supply.
4. Always electrically ground the machine properly.
5. It is advisable to keep the unit in a ventilated and dry place with a minimum of 20cm/6 in. clearance from all other objects.
6. Do not expose the machine to moisture.
7. Place the unit on the ground horizontally or hang on the truss at a downward angle of no more than 15°. Fasten the unit securely.
8. Use high quality liquid made specifically for Full Foggers. Fogger liquid should not be ingested. If fogger liquid comes in contact with skin or eyes, rinse thoroughly with water.
9. Always make sure there is sufficient liquid in the fogger liquid tank. Operation without liquid may cause permanent damage to the machine.
10. Never dilute the fog liquid with water, or any flammable liquids such as oil, gasoline, perfume, etc.
11. Do not touch the fog output area or the liquid input area.
12. Keep out of range of flammable and/or explosive materials.
13. Stay at least 2 feet away from the machine when it is in operation.
14. Machine components should only be changed by a professional technician.

WARRANTY

One (1) Year Limited Warranty

Subject to the limitations set forth below, Venue™ hereby represents and warrants that the components of this product shall be free from defects in workmanship and materials, including implied warranties of merchantability or fitness for a particular purpose, subject to normal use and service, for one (1) year (ninety (90) days for lamps) to the original owner from the date of purchase.

Retailer and manufacturer shall not be liable for damages based upon inconvenience, loss of use of product, loss of time, interrupted operation or commercial loss or any other incidental or consequential damages including but not limited to lost profits, downtime, goodwill, damage to or replacement of equipment and property, and any costs of recovering, reprogramming, or reproducing any program or data stored in equipment that is used with Venue™ products. This guarantee gives you specific legal rights. You may have other legal rights which vary from state to state. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.

Venue Lighting Effects
P.O. Box 5111
Thousand Oaks, CA 91359-5111
www.venuelightingeffects.com

All trademarks and registered trademarks mentioned herein are recognized as the property of their respective holders.
Made in China. 0804-8115.01

WWW.VENUELIGHTINGEFFECTS.COM

IMPORTANT SAFETY INSTRUCTIONS



This symbol is intended to alert the user to the presence of non-insulated “dangerous voltage” within the products enclosure.



This symbol is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the unit.



Apparatus shall not be exposed to dripping or splashing. Objects filled with liquids, such as vases, shall not be placed on the apparatus.



1. Read all safety and operating instructions before using this product.
2. All safety and operating instructions should be kept for future reference.
3. Read and understand all warnings listed on the operating instructions.
4. Follow all operating instructions to operate this product.
5. This product should not be used near water, i.e., bathtub, sink, swimming pool, wet basement, etc.
6. Only use dry cloth to clean this product.
7. Do not block any ventilation openings, it should not be placed flat against a wall or placed in a built-in enclosure that will impede the flow of cooling air.
8. Do not install this product near any heat sources such as radiators, heat registers, stoves or other apparatus (including amplifiers) that produce heat.
9. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding-type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the apparatus. Do not break the ground pin of the power supply cord.
11. Only use attachments specified by the manufacturer.
12. Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer or sold with the apparatus. When a cart is used, exercise caution when moving.
13. Unplug this apparatus during lightning storms or when unused for a long period of time.
14. Care should be taken so that objects do not fall and liquids are not spilled into the unit through the ventilation ports or any other openings.
15. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way.
16. **WARNING:** To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture.
17. When a mains plug or an appliance coupler is used as the disconnect device, the disconnect device shall remain readily operable.



**VENUE**[™]
LIGHTING EFFECTS