


ULTRA MINI-FOGGER USER MANUAL



VENUE ULTRA MINI-FOGGER USER MANUAL

Congratulations on your purchase of a new Venue Ultra Mini-Fogger. To get the most out of your Ultra Mini-Fogger, please read this user manual thoroughly.

I. Operation Directions

- Remove all the packing materials before use. Please contact the store if you find any broken or missing parts.
- 2. Place the machine horizontally, fill with fog fluid to the indicated level, and move the unused fog fluid away from the unit.
- 3. Connect the machine to the power supply (120VAC).
- 4. Wait until the indicator on the remote is lit before pressing the fog button.
- 5. It is normal for your fogger to have a recycling period after long bursts. At this point, the unit will shut down for a short period in order to heat back up. During this time, no fog will be produced. The red light on the back of the unit will illuminate when the unit is ready for fog production.
- 6. You should turn off the machine before refilling with fog fluid.

II. Maintenance

To keep your Mini-Fogger running smoothly, please clean after every 40 hours of use. Use a mixture consisting of 80% pure water and 20% vinegar as follows.

- A. Dismount and clean the nozzle with vinegar.
- B. Empty the tank, and then pour in the cleaning mixture. Spray fogger until it expels clean liquid.
- C. Re-attach the nozzle and fill unit with fog fluid.

III. Precautions

- To reduce the risk of fire, electric shock, or injury, place the product and AC cord where they will not fall.
- 2. To reduce the risk of electric shock, do not overfill fog fluid.
- To reduce the risk of electric shock, disconnect the power supply cord before cleaning the product or when removing the heating element.
- 4. Indoor use only. Do not expose product to any moisture.
- 5. Do not obstruct the nozzle.
- 6. Never aim the nozzle directly at people.
- Place product where there is good ventilation. Keep unit cool and away from other objects.
- 8. Keep away from children.
- 9. Keep away from flames, flammable or explosive substances.
- 10. Do not spray toward anyone.
- 11. Never use the machine when the liquid has spilled over.
- 12. Pour the fog liquid carefully to avoid overflow.
- 13. Never pour flammable liquids such as gas, perfume, etc., into the fog machine.
- 14. Switch off the machine if you are not going to use it for an extended period of time.
- 15. Only an electrician can repair or exchange the power cord.
- 16. No user-serviceable parts inside. If repair is required, please refer to your vendor.
- 17. For best results, use only high-quality fog juice such as Black Label.

IV. TECHNICAL SPECIFICATIONS

Rating Voltage:120V~60Hz, 3.5 AHeater:400 WattsFuse:F5A/125VPreheat Time:5 MinutesFog output:2000 CFMTank capacity:1.0 Liter

Dimensions: L342xW185xH190mm

IMPORTANT SAFETY INSTRUCTIONS



This symbol is intended to alert the user to the presence of non-insulated dangerous voltage within the products enclosure.



This symbol is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the unit.



Apparatus shall not be exposed to dripping or splashing. Objects filled with liquids, such as vases, shall not be placed on the apparatus.



CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE CHASSIS. NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.









- 1. Read all safety and operating instructions before using this product.
- 2. All safety and operating instructions should be kept for future reference.
- 3. Read and understand all warnings listed on the operating instructions.
- 4. Follow all operating instructions to operate this product.
- 5. This product should not be used near water, i.e. bathtub, sink, swimming pool, wet basement, etc.
- 6. Only use dry cloth to clean this product.
- 7. Do not block any ventilation openings. It should not be placed flat against a wall or placed in a built-in enclosure that will impede the flow of cooling air.
- 8. Do not install this product near any heat sources, such as radiators, heat registers, stoves or other apparatus (including amplifiers) that produce heat.
- 9. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades, with one wider than the other. A grounding-type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
- 10. Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the apparatus. Do not break the ground pin of the power supply cord.
- 11. Only use attachments specified by the manufacturer.
- 12. Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer or sold with the apparatus. When a cart is used, exercise caution when moving.
- 13. Unplug this apparatus during lightning storms or when unused for a long period of time.
- 14. Care should be taken so that objects do not fall and liquids are not spilled into the unit through the ventilation ports or any other openings.
- 15. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way.
- 16. WARNING: To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture.
- 17. When a mains plug or an appliance coupler is used as the disconnect device, the disconnect device shall remain readily operable.



One (1) Year Limited Warranty and Remedies.

Subject to the limitations below, Venue™ warrants to the original owner that the components of this product are free from defects in workmanship and materials, subject to normal use and service, for one (1) year from the date of purchase. VENUE™ MAKES NO OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OR ANY IMPLIED WARRANTY ARISING OUT OF A COURSE OF DEALING, CUSTOM OR USAGE OF TRADE. User is responsible for determining whether this product is fit for a particular purpose and suitable for user's application. If the product is defective within the warranty period, user's exclusive remedy and manufacturer's sole obligation will be, at its option, to replace the product or refund the purchase price. Except where prohibited by law, manufacturer and seller will not be liable for any loss or damage arising from the product, whether direct, indirect, special, incidental or consequential, regardless of the legal theory asserted, including warranty, contract, negligence or strict liability.

California Prop 65 Warning

This product may contain a chemical known to the state of California to cause cancer or birth defects or other reproductive harm.

VENUE, P.O. Box 5111, Thousand Oaks, CA 91359-5111

www.venuelightingeffects.com

All trademarks and registered trademarks mentioned herein are recognized as the property of their respective holders. Made in Taiwan 807-8203.01

